

Screen captures

- on the oscilloscope, go to
 - Utility > Options
 - Printer Setup
 - Portrait
 - TIFF/PCX
 - RS232
 - RS232 Setup
 - Set to defaults

Baud	9600
Flow control	Hard flagging
EOL string	LF
Parity	none

- press "Print"/"Hardcopy" to start transfer

Hyperterminal

- "New Connection"
- name it something, pick COM2

Baud	9600
Data bits	8
Parity	None
Stop bits	1
Flow control	Hardware

- Transfer > "Capture Text..."
 - name the file something
 - stop the transfer when done

- use cursors and measure tools in screen caps